



Carlo Gavazzi

## ESAVTR20VD

Gawo la Nambala:  
 Wopanga / Chinthu:  
 Mafotokozedwe Akatundu  
 Datasheets:  
 Zolembe  
 Chombo Chochokera  
 Njira Yopereker

ESAVTR20VD  
 Carlo Gavazzi  
 AIR-SPD/TEMP 0-10V OUT  
  
 175 pcs stock  
 Hong Kong  
 DHL/Fedex/TNT/UPS/EMS

**PEMPHO LA QUOTATION**

Chithunzi chingakhale choyimira. Onani ndondomeko zogwiritsira ntchito mankhwala.

### Mafotokozedwe a ESAVTR20VD

GAWO LA NAMBALA	ESAVTR20VD
WOPANGA	Carlo Gavazzi
KUFOTOKOZERA	AIR-SPD/TEMP 0-10V OUT
MKHALIDWE WOPANDA UFULU / MKHALIDWE WA ROHS	
CHIWERENGERO CHIPEZEKA	175 pcs
TSAMBA LAZAMBIRI	
MNDANDANDA	-
MTUNDU WA SENSOR	Humidity, Temperature
MTUNDU WOTSATSA	-
KUTENTHA KWAMBIRI	0°C ~ 50°C (TA)
MPHUNO YOPANDA CHISOKONEZO (MSL)	Not Applicable
KUFOTOKOZEDWA KWAMBIRI	Humidity, Temperature Sensor Output

### Matanthauzo okhudzana

Carlo Gavazzi ESAVTR20VD	AAAA Distributor	ESAVTR20VD Wopereka
ESAVTR20VD Mtengo	ESAVTR20VD Zithunzi	ESAVTR20VD Image
ESAVTR20VD PDF Datasheet	ESAVTR20VD Dinani Datasheet	ESAVTR20VD Datasheet
ESAVTR20VD Stock	Gulani ESAVTR20VD	Gulani Carlo Gavazzi ESAVTR20VD
Carlo Gavazzi ESAVTR20VD	Carlo Gavazzi Wogulitsa	Carlo Gavazzi Distributor
Carlo Gavazzi ESAVTR20VD		

### Zogwirizana

<p><b>ESAVTR20A</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 4-20MA OUT                  Zilipo: 180 pcs  <a href="#">RFQ</a></p>	<p><b>ESAVTR20ADM</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 4-20MA OUT                  Zilipo: 160 pcs  <a href="#">RFQ</a></p>
<p><b>ESAVTR20AD</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 4-20MA OUT                  Zilipo: 135 pcs  <a href="#">RFQ</a></p>	<p><b>ESAVTD20VM</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 0-10V OUT COM                  Zilipo: 184 pcs  <a href="#">RFQ</a></p>
<p><b>ESAVTR20V</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 0-10V OUT                  Zilipo: 188 pcs  <a href="#">RFQ</a></p>	<p><b>ESAVTD20AM</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 4-20MA OUT W/COM                  Zilipo: 182 pcs  <a href="#">RFQ</a></p>
<p><b>ESAVTR20VDM</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 0-10V OUT                  Zilipo: 158 pcs  <a href="#">RFQ</a></p>	<p><b>ESAVTR20AM</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 4-20MA OUT                  Zilipo: 160 pcs  <a href="#">RFQ</a></p>
<p><b>ESAVTD20V</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 0-10V OUT                  Zilipo: 192 pcs  <a href="#">RFQ</a></p>	<p><b>ESAVTR20VM</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 0-10V OUT                  Zilipo: 171 pcs  <a href="#">RFQ</a></p>
<p><b>ESAVTD20VD</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 0-10V OUT                  Zilipo: 182 pcs  <a href="#">RFQ</a></p>	<p><b>ESAVTD20VDM</b>                  Opanga: Carlo Gavazzi                  Kufotokozera: AIR-SPD/TEMP 0-10V OUT COM                  Zilipo: 133 pcs  <a href="#">RFQ</a></p>